

Pratt Safety Shower Test Kit.

Release Date: October 2011

With the introduction of the new Australian Standard “**Emergency Shower and Eye Wash Equipment**” AS 4775-2007, it reinforces the need for regular testing and maintenance. However there has not been a recognized Testing Kit available to assist with the testing of this type of equipment.

Pratt Safety Systems has recognized this issue and developed a Testing Kit specific for this application.

This new kit provides the necessary equipment to perform all of the tests and checks required, in order to comply with the Standard.

Safety Shower and Eye Wash Equipment provide a vital role in the initial treatment for many chemical burns and contaminations, fire burns and freeze burns. Whilst businesses are required to provide this type of equipment, where hazards exist, in many cases the equipment is not correctly tested and maintained to ensure correct operation at all times. This is often the result of not having the necessary equipment, procedures and knowledge to perform these tasks.

To order:

SETESTKIT - Complete Safety Shower Test Kit

or

SE950 - Shower Test Sock & Receptacle Kit



Part No: SETESTKIT

Description: Safety Shower Test Kit



Part No: SE950

Description: Shower Test Sock & Receptacle Kit.

Please contact your Distributor or Pratt Customer Service for further information.

The Pratt Safety Systems' new Safety Shower and Eye Wash Test Kit comprises of the following list of components:

- **Shower Test Bin** - 120L yellow plastic portable bin fitted with clear plastic site gauge and capacity indication for every 5 litres. Also includes drainage valve. This enables the testing of flow rates or weekly flushing for the safety shower when used in conjunction with the Shower Test Sock.
- **Shower Test Sock** – Made of a soft nylon sock material with an aluminium frame and handle assembly. Can be used with Shower Test Bin or 20L plastic receptacle.
- **Shower Pattern Test Gauge** – This is a floor mounted stand made of collapsible aluminium tube. This measures the correct flushing fluid pattern at the correct height by placing under the shower head. It can also be used to with the Shower Test Sock to provide a hands free operation.
- **Eye Wash Test Gauge** – This is a clear plastic plate with engraved markings and instructions, This measures the flushing fluid pattern of the eye wash.
- **PVC Document Holder** – A water proof holder to store instructions and check lists along with the eye wash gauge, spare tags and aerator key for safe storage.
- **Eye Wash Aerator Removal Key** – Made of stainless steel and has been designed to enable the removal and refitting of the aerators as used in many eye wash stations.
- **Laminated Shower & Eye Wash Check List** - Includes check lists for both weekly and annual tests. Simply photo copy the check lists to record the test results for each shower and eye wash. Also includes laminated instructions and summary log sheet.
- **Shower and Eye Wash Test Tags** - Includes one packet of 10 water proof test tags. Secure to the shower or eye wash and record the date for each test. Additional tags available, sold as packet of 10.
- **20L Plastic Receptacle** - Can be used as alternative for test bin, to conduct brief shower flushing when used with the Shower Test Sock. Includes lid.
- **Flexible Plastic Hose** - 1.5 m length x 38 mm ID flexible tube for use with combination shower & eye wash stations, to drain the eye wash into low profile plastic tray from the rear outlet on stanchion.
- **10 L Plastic Tray** - Used to collect waste fluid from the eye wash when weekly flushing or testing for flow rates.
- All of the components included in the Shower Test Kit can be easily stored with the Test Bin ready for the next flushing or testing programme.

By using the Pratt Safety Shower and Eye Wash Test Kit, in conjunction with your own safety procedures, will enable you to ensure that your Emergency Safety Shower and Eye Wash Equipment, are maintained and can perform in accordance with AS 4775-2007.programme.

